- Set the desired number with the setting wheel alone
- Press the button M

CINE — Setting shutter angles other than 180°

- Use setting wheel to set the desired angle

Photometry

- Set the diffuser ring at the meter head to the desired measuring function
- Use setting Function button and setting wheel to select the corresponding measuring function
- Press the button M

Please refer to the enclosed comprehensive instruction manual for detailed instructions.

GOSSEN Foto- und Lichtmeßtechnik GmbH Lina-Ammon-Straße 22 D-90471 Nürnberg

Fon: +49 911 / 8602-181 Fax: +49 911 / 8602-142 http://www.gossen-photo.de

GOSSEN

GOSSEN

Use DIP Switches in the battery compartment for setting and selecting function groups and measuring capabilities.

Setting the film speeds

- Press and hold the ISO or ISO 2 button
- Set the desired ISO value using the setting wheel, e.g. 200
- The corresponding values for ISO 2 are automatically calculated and displayed based on the measuring results for ISO

Measuring modes

Select incident light or reflected light at the diffusor ring

Ambient light


- Release Function button
- Set the desired f/stop or exposure time with the setting wheel alone
- Press the button M

ENG

GOSSEN

Starlite

Condensed Instructions 15100 • 1/05.01



Flash light

- Press the right Function button

 to select flash light

 1
- Preselect the desired measuring time (sync speed) with the setting wheel
- Press the button M
 Cord: the flash is being automatically
 triggerd when pressing M
 Noncord: for 45 s the meter is ready
 for manual triggering of the flash

Contrast measurements

Keep M depressed and scan subject

Averaging

- Take first measurement with button M
- Take further measurements with M

CINE / PHOTOMETRY

Set DIP switch 1 in battery compartment to CINE

CINE

- Press and hold the left Function button ⓓ and use the setting wheel to select measuring unit ☒
- Release Function button